

On / Off and Standby Mode

Hold down power button for 3 seconds and indicator will flash then go solid blue. This means the device is now in standby mode.

Error: If the indicator continues to flash and then turns off the Micro SD card is not being detected or has not been inserted properly.

To turn the device off, when in standby mode press the "ON/OFF" button for three seconds. The indicator will flash three times and go out.

Take a picture

To capture a picture, in standby mode, press the "REC/PHO" button once. When successful the indicator will flash once and go back in to standby mode.

Record just audio

When in standby mode press the "REC/PHO" button for 3 seconds. The indicator will flash 3 times and go out, the device is now recording audio.

To stop recording audio, press the "REC/PHO" button once. The indicator will go solid blue stating the device is in standby mode.

Take a video

In standby mode press the "VIDEO" button once and the indicator will flash twice and go out. The device is now recording video. To stop recording, press the "VIDEO" button once and the device will go back in to standby mode.

Motion Detection

When in standby mode press and hold the "VIDEO" button for 3 seconds. The indicator will flash 5 times and then go out. When the device detects motion the indicator will flash once and begin recording.

To stop motion detection, press the "VIDEO" button once and the device will go back in to standby mode.

Infrared

In the video or motion detection mode press the "REC/PHO" and this will turn on the infrared. To stop recording, press the "VIDEO" button once and the device will go back in to standby mode with the infrared now off.

Charging

When charging the indicator will flash blue and red simultaneously. When fully charged the light will flash blue.